




HP Pavilion x360 15t-br000 Battery Replacement

Use this guide to replace the battery in your HP Pavilion x360 15t-br000.

Written By: xi yang



INTRODUCTION

Use this guide to replace the battery in your HP Pavilion x360 15t-br000 laptop.

If your battery is damaged, you can't open the laptop. A damaged battery may cause the laptop to shut down and you will lose your data.

Don't connect to the power when doing the replacement.

TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [Metal Spudger](#) (1)

Step 1 — Keyboard Panel




- Remove the covers to access the screws attached to the back cover of the device.
- Remove six 3mm screws using the Phillips #0 screwdriver.

Step 2




- Use a metal spudger to loose the four corners of the keyboard panel. The corner is circled red shown in the first image.
- Disconnect the keyboard panel cables under the upper case.
- Remove the keyboard panel from the device.

Step 3 — Battery



- Disconnect the battery cable from the device.

Step 4



- Remove the seven Phillips #0 4.5 mm screws.
- Remove the battery from the device.

To reassemble your device, follow these instructions in reverse order.