



# HP Pavilion zd8000 RAM Replacement

Written By: Allie Menard



## INTRODUCTION

Removing the RAM from this device is straightforward and requires little disassembly.

### TOOLS:

- Phillips #1 Screwdriver (1)

### PARTS:

- PC2-5300 1 GB RAM Chip (1)
- PC2-5300 512 MB RAM Chip (1)

## Step 1 — Battery

- Slide the battery release latch towards you.



## Step 2



- Pull up on the battery to remove it.

## Step 3 — RAM




- Loosen the Phillips screw labeled 'ram' and lift the cover.

## Step 4



- Locate the green RAM card and find the metal tabs securing the card.
- Push outwards on the two tabs to release the card.

## Step 5



- Carefully slide the card out at an upward angle away from the slot.

To reassemble your device, follow these instructions in reverse order.