



HP ProBook 4320t Power Button Panel Replacement Guide

Replacing a bent or scratched power button panel.

Written By: Joshua



INTRODUCTION

The power button panel is one of the easiest components to replace on the HP 4320t. It may need replacing, if damaged, to insure proper working order.

TOOLS:


- Phillips #0 Screwdriver (1)

Step 1 — Battery Removal



- Flip the laptop upside down and remove battery by pressing inward on the two latches holding the battery in.

Step 2 — Screws



- Unscrew the four (2.5 mm Phillips) screws (Use Phillips #0 Screwdriver).

Step 3 — Flip



- Flip laptop over and open it.

Step 4 — Push N Lift



- Slightly push up while lifting up on the power button panel to release the panel.

To reassemble your device, follow these instructions in reverse order.