



HP ProBook 450 G3 Battery Replacement

This guide will tell you how to replace the battery for HP ProBook 450 G3.

Written By: Jingyuan Zhang



INTRODUCTION

This guide will tell you how to replace the battery for HP ProBook 450 G3.

Step 1 — Battery



⚠ Make sure you turn off the laptop before you start.

- Push the release on the right side of the computer to the center.
- Push and hold the release on the left side of the computer towards the center.

Step 2



- Once the releases are in position, pull the battery out.

To reassemble your device, follow these instructions in reverse order.