



HP Touchsmart IQ506 Stand Replacement

If your stand on your HP IQ506 has failed, this is how you replace it.

Written By: Nick



INTRODUCTION

Replacing the stand on the HP IQ506.

The part number for the stand this system uses is the HP 507866-001 stand. Note: This part does not include screws. You will need to get the diameter with a digital caliper if you do not have the screws. I DO NOT have this information to hand right now.

TOOLS:

- 64 Bit Driver Kit (1)

PARTS:

- Stand (HP Part Number 507866-001) (1)

Step 1 — Unplug the power supply



- Unplug the power supply from the system.

Step 2 — Remove the RAM door



- Unscrew the RAM door from the system. Use a **Phillips #1** screwdriver. Once you do this, unclip it from the bottom and pull forward.

Step 3 — Screwdriver placement tip



- The top screws on the hinge are a burden to remove. You will have to do something like the pictures here show to make it go a little easier.

Step 4 — Remove the stand



- Remove the stand from the system. Use a **Phillips #1** screwdriver to loosen the 4 screws. Grab the stand up to remove it from the system. There is no need to force it off.

To reassemble your device, follow these instructions in reverse order.