




HP dv5-1125nr Disk Drive Replacement

This drive will show you how to replace your optical disk drive.

Written By: Nick Loey




INTRODUCTION

Replacing your optical drive is not a complex process. Follow this guide to learn how!

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

Step 1 — Battery



- **Ensure your computer is shut down.**
Removing the battery while the laptop is still on may corrupt your files. Remove any power adapters and cords connected to the laptop body.
- **Slide the switch to the left until the release clicks.**

Step 2





- **Remove the battery.**
- **The release switch may need to be held down while removing the battery.**

Step 3 — Disk Drive



- Locate two 3mm Phillips screws on the CMOS panel cover and remove them with a Phillips #00 screwdriver.
- Remove the CMOS panel cover.

Step 4



- The optical drive is now ready for removal. Using a plastic removal tool, lift the optical drive away from your computer.
- Using your hands, slide the remainder of the drive out of the computer.

To reassemble your device, follow these instructions in reverse order.