



# HP eStation Zeen Battery Replacement

This guide is used to replace the battery of the HP eStation Zeen.

Written By: dalton hale



## INTRODUCTION

After following the troubleshooting procedures and the device still will not turn on it may be time to replace the battery.

### TOOLS:

- Phillips #0 Screwdriver (1)
- Metal Spudger (1)
- iFixit Opening Tools (1)

## Step 1 — Battery




- Remove the screw caps using a metal spudger.
- Remove the four 6mm screws using a Phillips #0 screwdriver.

## Step 2



- Unclip each side by inserting a plastic opening tool and slide it along edges.
- Remove the back panel by lifting the panel away from the device.


## Step 3



- Disconnect the battery clip with a plastic opening tool.

 The clip is very fragile.

## Step 4



- Remove the battery using the plastic opening tool.

 There is glue holding the battery down so it will require some effort.

To reassemble your device, follow these instructions in reverse order.