



HP pavilion 15-cs3073cl Disassembly

Disassembly of the laptop to easily access hdd, battery, RAM, and more

Written By: Josue Nolasco



 **TOOLS:**

- Phillips #00 Screwdriver (1)
- Phillips #0 Screwdriver (1)
- Prying and Opening Tool Assortment (1)

Step 1 — Remove front screws



- Begin by removing the 3 screws on the bottom front of the laptop. A Phillips #00 works well here.

Step 2 — Remove hidden screws



- There are 3 screws hidden under the rubber pads. Using a pry tool or something thin like a credit card to remove the glued on rubber pads you will find one screw on the left back and 2 under the right pad. Phillips #0 works well to remove these larger screws.

Step 3 — Pry the upper and lower body



- With a thin pry bar or credit card push in between the upper and lower parts of the body and you'll hear a clicking sound as the tabs release the 2 pieces. Go all around the laptop until the bottom cover is completely off.

Step 4 — HDD removal



- If you're upgrading the HDD remove the 2 screws on the exposed side and lift from that side. The other side

is being held by 2 rubber nipples on a thin rubber strip that will bend as you pull the drive.

To reassemble your device, follow these instructions in reverse order.