



# HP-Pavillion 500-424 PC Series CPU Fan Replacement

This guide is to help you accomplish replacing the CPU fan in your HP desktop computer.

Written By: Amanda Milby



## INTRODUCTION

If the CPU fan becomes to filled with dust or stops spinning, it must be replaced immediately. If it is not replaced then the CPU or motherboard can become damaged and cause the computer to be unbootable

### TOOLS:

- 10 Bit Screwdriver Set (1)  
*#6 Flat Head bit and the PH.1 bit*



### PARTS:

- HP Pavilion 500-424 PC Series CPU Fan (1)

## Step 1 — Central Processor Fan




- Lay the tower down carefully on its right side, with the vents pointing up.

## Step 2



- Use the flat head #6 screwdriver bit to unscrew the tower casing.
- Very gently slide the case towards you.
- Lift the casing up and gently place it off to the side.

## Step 3



- Unplug the fan from the motherboard by gently grasping the connector and slowly pulling up.
- Remove each screw from the fan using the Phillips head screwdriver bit.
- ☒ Place the screws in a cup, they are very small and can be lost easily.
- Remove the old fan from the CPU.

To reassemble your device, follow these instructions in reverse order. Now you should feel confident replacing the CPU fan in your HP desktop without any difficulties.