




HTC Desire 826 Back Camera Replacement

How to replace your back camera to your HTC Desire 826.

Written By: Jordan Warnix



INTRODUCTION


This guide will help you with replacing your back camera of your HTC Desire 826.



TOOLS:



- [T5 Torx Screwdriver](#) (1)
 - [Tweezers](#) (1)
 - [Magnetic Project Mat](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Battery




- Find a seam in the back of the device
- Insert the plastic spudger into the seam and pry off the back panel
- ⓘ There will be glue, so keep prying until it comes off or you may need to heat up the edges of the device to loosen the adhesive with the [iOpener](#).

Step 2




- Remove the 4.0 mm screw above the battery with the T5 screwdriver.
- Remove the metal covering with the tweezers

Step 3






- Disconnect battery cable attached to the motherboard with the tweezers.

Step 4




- Lift battery with plastic spudger and remove

Step 5 — Back Camera






- Use the T5 screwdriver to remove the three 4.0 mm screws as shown.

Step 6



- Use the spudger to lift the black plastic covering.

Step 7



- Use the spudger to lift the green board. The back camera is attached on the side as shown.
- Use the tweezers to disconnect and remove the camera.

To reassemble your device, follow these instructions in reverse order.