



HTC Desire SD Card Replacement

Replace SD card in HTC Desire.

Written By: Hunter Kent



 **TOOLS:**

- [Spudger \(1\)](#)

 **PARTS:**

- [16 GB SD Card \(1\)](#)

Step 1 — Battery



- Insert flat end of spudger into slot on the top of phone to pry off the back plate.

Step 2



- Use flat edge of spudger to lift the bottom right corner of the battery.
- Lift the battery out of the phone.

Step 3 — SD Card



- Remove SD card and replace with a new one.

To reassemble your device, follow these instructions in reverse order.