



HTC One M8 SIM Card Replacement

Replace the SIM card.

Written By: Geoff Wacker



INTRODUCTION

Use this guide to replace the SIM card on your HTC One M8.

TOOLS:

- [SIM Card Eject Tool \(1\)](#)

PARTS:

- [HTC One \(M8\) SIM Card Tray \(1\)](#)

Step 1 — SIM Card



- Insert a SIM card eject tool or a paperclip into the small hole in the SIM card tray, located on the upper left hand side of the phone.
- Press to eject the tray.

(i) This may require a significant amount of force.

Step 2



- Remove the SIM card tray assembly from the HTC One M8.



When reinserting the SIM card, ensure that it is in the proper orientation relative to the tray.

To reassemble your device, follow these instructions in reverse order.