



HTC One M9 MicroSD Card Replacement

Replace the microSD card.

Written By: Geoff Wacker




INTRODUCTION

Use this guide to replace the microSD card on your HTC One M9.

TOOLS:

- [SIM Card Eject Tool \(1\)](#)

Step 1 — MicroSD Card



- Insert a microSD card eject tool or a paperclip into the small hole in the microSD card tray, located on the upper right hand side of the phone above the volume buttons.
- Press to eject the tray.
 - ⓘ This may require a significant amount of force.
- ⓘ When reinserting the microSD card, ensure that it is in the proper orientation relative to the tray. The contacts should be inserted first and face to rear side.
- ⓘ It is normal, that the microSD card doesn't stay on its own inside the tray. It is also not completely trivial to place it correctly flat inside the tray.

To reassemble your device, follow these instructions in reverse order.