



# HTC Rhyme Volume Button Replacement

Written By: Frederick



 **TOOLS:**

- [Spudger \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [Phillips #0 Screwdriver \(1\)](#)

 **PARTS:**


- [HTC Rhyme Metal Frame \(1\)](#)

## Step 1 — Removing Back Cover



- Slide the bottom back cover off of the phone.

## Step 2




- Locate the four screws on the plastic cover and unscrew them.

## Step 3




- Pry the sticker off from the sides.
- You can use a metal spudger to do this.
- Peel the sticker off with your hands.

## Step 4 — Remove the plastic cover



- Remove the plastic cover using your hands.

## Step 5



- Remove the yellow ribbon.

## Step 6




- Lift up the blue flaps underneath the battery.
- Lift up the black flap at the top of the phone.
- Lift up the black flap at the bottom of the phone.

## Step 7 — Remove the Motherboard



- Remove all 4 screws.
- Carefully remove the motherboard with your hands.

## Step 8 — Removing the back plastic casing



- Pry the back plastic casing off with your hands.

## Step 9



- Use the tip of a screwdriver to push the button out of the panel.

To reassemble your device, follow these instructions in reverse order.