




Handset Microphone Replacement

This guides you through replacing a faulty microphone on your Sony SPP-A946 handset.

Written By: Han Shih



INTRODUCTION

This will walk you through replacing the microphone on the handset.

TOOLS:

- Metal Spudger Set (1)
- Phillips #0 Screwdriver (1)

Step 1 — Handset



- After removing the BP-T18 battery pack, you will see two 11mm Phillips #0 screws located at the bottom of the phone. Remove both screws with a screwdriver.



 Product is made of brittle plastic.

Step 2




- Locate an easy point of access for a spudger, and then slowly insert it into the gap and pry it open.
- (i)* The opening should become bigger if you exert force at a 30 degrees angle.
- Increase the degree of slant until the back cover is completely removed.

Step 3



- After removing the back cover, you will see 3 screws: one 7mm Phillips #0 screw at the top and two 11mm Phillips #0 screws at the bottom.
- Use a screwdriver to remove all 3 screws.

Step 4 — Handset Microphone



(i) After disassembling the handset, you will see the inner components of the handset.

- Locate the rubber part towards the very bottom of the handset. This is the microphone with protective rubber cover.
- Remove the protective rubber cover. This may require a spudger.

! The microphone is exposed upon removal of the protective rubber cover. Avoid contact with water.

To reassemble your device, follow these instructions in reverse order.