



Honeywell HF-910 Fan Teardown

How to take apart the Honeywell HF-910 Fan.

Written By: Jonathan Wood



INTRODUCTION

This is a guide to take apart the Honeywell HF-910 Fan. This guide will allow you to clean the fan or replace broken parts.

TOOLS:

- Phillips #0 Screwdriver (1)

Step 1 — Removing fan cage



- First, locate 6 screws along the cage of the fan
- Remove these 6 screws with phillips head screwdriver
- Remove cage of fan

Step 2 — Removing Fan Blade



- The fan should now look like the first picture
- Locate the two phillips head screws behind the blades
- Remove these screws

Step 3 — Removing Motor



- Remove the two screws that are circled in the photo
- The motor becomes loose with only the wires holding it in place

Step 4 — Accessing Speed Control Connection



- Remove the screw that is circled in the first picture to access the speed control wires
- The wires connecting to the speed controller are shown in picture #2

Step 5 — Remove Power Supply



- Remove the circled screw in order to access the power supply

Step 6



- To reassemble device, follow these instructions in reverse order.