



# How to Connect the Camera to Your Phone

This guide will show how to connect your camera to your phone to transfer files.

Written By: Rupinderpal Singh



## INTRODUCTION

The Samsung NX30 has the cool feature of sending photos directly from the camera to phone. This guide will teach you how to do it quickly and with ease.

### **TOOLS:**

- [Samsung Smart Camera App \(1\)](#)

## Step 1 — How to Connect the Camera to Your Phone





- To begin you must have the Samsung Smart Camera App on your phone. You can install this for free from the App Store.

## Step 2





- Next you have to put the camera on Wifi mode.
- Then choose the MobileLink application that will appear on the screen when you have changed the camera to Wifi mode.
- Then select the option to send files from camera.

## Step 3



- On your phone, connect to the Wifi network your camera is sending out (Phone must have the wifi on)
- The Wifi network name may have a similar name to: "AP\_SSC\_NX30\_0-79:1C:EA."

## Step 4



- On the camera, you will have to choose the pictures to send to the phone.
- Click on each image you would like to send.
- Hit the send button on the camera screen to send the selected pictures!
- Finally, you can see the photos that were sent on the Samsung Smart Camera App on your phone.