



# How to Factory Reset a Fitbit Versa Smart Watch

This guide will show you how to factory reset a fitbit versa smart watch. A factory reset will restore your device to factory settings.

Written By: Mike

## Step 1 — How to Factory Reset a Fitbit Versa Smart Watch



- How to factory reset a Fitbit Versa Smart Watch

## Step 2



- Open the settings app. It looks like a little gear icon.

## Step 3



- Click the about button.

## Step 4



- Click Factory Reset.

To reassemble your device, follow these instructions in reverse order.