



# How to Fix a Squeaky Door Hinge

Fix a squeaky door by removing and oiling the hinge pin.

Written By: Jake Herson



## INTRODUCTION

Squeaky doors are a constant nuisance around most households. Use this guide to take apart a door hinge, oil it, and reassemble it. This easy repair should help quiet any squeaky door.

### TOOLS:

- Hammer (1)
- Flathead 3/32" or 2.5 mm Screwdriver (1)
- Bowl (1)
- Towel (1)
- Paintbrush (1)

## Step 1 — How to Fix a Squeaky Door Hinge



- Insert the end of the flathead screwdriver into the crease between the top of the pin and the hinge.

## Step 2



- Take the hammer and hit the handle end of the screwdriver until the pin can be pulled out. This may take a while depending on the door.

## Step 3



- Place the pin in a bowl of mineral oil (or other household lubricant) and let it rest.

## Step 4



- Use a brush to apply oil to the empty hinge.

## Step 5



- Take the pin from the bowl and reinsert it into the door hinge, using a hammer if necessary.

## Step 6



- Open and close the door a few times. This will help the oil to seep into the cracks of the hinge.

## Step 7



- Use a towel to catch any drips of oil and to wipe off the hinge.

The door should now be quite silent when opening and closing. Thank you for reading.