



How to Force Restart an iPhone 11 Pro Max

Perform a full reboot (a.k.a. force restart) to help troubleshoot or "unfreeze" an iPhone 11 Pro Max.
This does not erase any data or settings.

Written By: yvaneck



INTRODUCTION

Performing a force restart should not delete any data, but it can be useful if your iPhone 11 Pro Max is frozen or needs troubleshooting.

Step 1 — How to Force Restart an iPhone 11 Pro Max



- Quickly press and release the Volume Up button (1).
- Quickly press and release the Volume Down button (2).

Step 2



- Finally, press and hold the side button (3) until the Apple logo appears, and then release.
- The screen will temporarily go dark as the iPhone shuts down and reboots. Keep holding the button until you see the Apple logo. Save

You're finished!