



How to Open a 17 Inch iMac Flat Panel Disassembly

This guide will show you how to open your 2002 17" iMac G4 Flat Panel

Written By: Milo




Step 1 — Place iMac Facedown



- Insert wisdom here.

Step 2 — Unscrew Four PH1 Philips Screws




- Bust out your iFixit toolkit and loosen these four PH1 Phillips screws.
- These screws will not fully come out!!

Step 3 — Remove Bottom Plate



- Remove the iMacs bottom plate to reveal the first of the goodies waiting inside.
- Since the screws don't fully come out, you can use them as a handhold to help remove the bottom plate.

Step 4 — Opening the Plastic Case



- Remove the 4 Torx T10 Screws

To reassemble your device, follow these instructions in reverse order.