



How to Prepare the Barreto Trencher E718MTH4S 2016 for Service

Prerequisite-only guide to turn off and immobilize the Barreto Trencher E718MTH4S 2016 before servicing.

Written By: Adam O'Camb



This document was generated on 2020-01-19 01:45:42 PM (MST).

INTRODUCTION

Prerequisite-only guide to make sure the Barreto Trencher E718MTH4S 2016 is off and immobilized prior to servicing.

Step 1 — Engage the hub lock pins



- Make sure that both ignition switches are turned to the off position. There is one on the engine and one on the control panel.
- Pull the ring near one of the wheel hubs straight out, away from the wheel.
- Rotate it so that the small roll pin lines up with its slot.
- Release the ring so that the lock pin slides into the wheel. You may need to rotate the wheels a little before the lock pin fully engages.
- *(i)* With the pin engaged, it should be very hard to turn the wheels.
- Repeat this step so that the lock pins on both wheels are engaged.

To reassemble your device, follow these instructions in reverse order.