



# How to Start a dead Acer Aspire 4743Z-4861

PC will start even though it appears dead when AC adapter is plugged in or power button is depressed.

Written By: Howard R Conant

## INTRODUCTION

All indications are that the PC is dead. I verified that the power adapter is producing 19.2 volts DC, replaced a weak battery and still the PC appeared dead. After pushing the power button scores of time, it booted up, proving that it was not dead, just faulty.

To start the computer, remove the AC adapter plug. On the bottom of the computer, release the battery lock and rotate the battery far enough to break its connection to the computer. After relatching the battery, press the power button and the computer should boot up. Then attach the power adapter.

This machine works normally after the above procedure. However, when shutting down, the power adapter will not charge the battery, and startup requires the same procedure as above... every time.

To reassemble your device, follow these instructions in reverse order.