



How to repair the vibrator of Huawei P8 lite?

This video shows you how to repair Huawei P8 Lite vibrator. Your p8 lite may not able to vibrate when receiving a phone call or vibrate in alarms.

Written By: Witrigs



INTRODUCTION

[video: <https://www.youtube.com/watch?v=sP6LIWSfqzE>]

After a long time usage, problems may occur on the vibrator. Your devices may not able to vibrate when receiving a phone call or vibrate in alarms. DIY to fix it. This video shows you how to repair Huawei P8 Lite vibration motor.

TOOLS:

- Spudger (1)
- T3 Torx Screwdriver (1)
- Phillips #000 Screwdriver (1)
- Tweezers (1)
- Jimmy (1)

PARTS:

- huawei p8 lite vibrator (1)

Steps:

Step1 Remove the back cover and the card trays;

Step2 Remove the plastic holder, the plastic shield and the power button flex;

Step3 Remove the loudspeaker and the metal shield;

Step4 Take out the motherboard;

Step5 Change the vibration motor;

Step6 Put back the motherboard;

Step7 Install the power button flex, the plastic shield and the plastic holder;

Step8 Install the metal shield and the loudspeaker;

Step9 Test the vibration motor;

Step10 Put back the card trays and fasten the back cover.