




How to replace LCD connector on a A1465 MacBook Air

Step by Step instructions for repairing LCD backlight circuit on A1465 MacBook Air 11" Main Logic Board 820-00164-A

Written By: Forza Vale



INTRODUCTION

Step by Step instructions for repairing LCD backlight circuit on A1465 MacBook Air 11" Main Logic Board 820-00164-A

TOOLS:

- STEREO MICROSCOPE (Optional) (1)
- Hot Air Rework Station Hakko FR-810 (1)
- Flux Pen 10ml No Clean (1)
- Desoldering Braid (1)
- Tweezers (1)

To reassemble your device, follow these instructions in reverse order.