



Hp 15-f305dx Keyboard Replacement

This guide will instruct you on how to replace your Hp 15-f305dx keyboard.

Written By: Brandon



 **TOOLS:**

- Phillips #0 Screwdriver (1)

Step 1 — Keyboard





- After Removing the battery, flip the laptop around.

Step 2




- Remove the 7mm Ph1 Phillips head screws on the top middle of the laptop

Step 3



- Take apart the keyboard from the laptop gently and flip the keyboard around

Step 4



- Disconnect the connected tag from the mainboard

To reassemble your device, follow these instructions in reverse order.