




# Huawei Ascend G610 Replacement proximity brightness sensor

Follow this repair guide if you have problems with the brightness sensor in your device

Written By: Smilzo



## INTRODUCTION

Follow this repair guide if you have problems with the brightness sensor in your device

## Step 1 — Proximity brightness sensor



- Remove back cover

## Step 2




- Remove battery

## Step 3



- With the help of a Phillips screwdriver, remove the 9 side screws, one is located under the adhesive

## Step 4




- With the help of a thin tool, pry up the side joints to remove the central body

## Step 5



- Unhook the display connector

## Step 6



- Unclip the touchscreen connector

## Step 7



- Unclip the brightness sensor connector

## Step 8



- Unhook the connector that connects the motherboard to the dock

## Step 9




- With the help of a thin tool, uncouple the mother board interlocked on the plastic hooks

## Step 10



- Remove motherboard

## Step 11



- With the help of a heat source of the tweezers remove proximity and brightness sensor by replacing it with a new one

To reassemble the device, follow these instructions in reverse order.