



# Huawei M750 Speaker Replacement

This guide will show how to fix or replace the speaker of the Huawei M750 cellphone.

Written By: Sebastian Solis



## INTRODUCTION

If you are experiencing issues with your phone's speaker, this guide will show you how to repair or replace it.

### **TOOLS:**

- [T5 Torx Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

## Step 1 — Battery



- Depress the top of the battery cover, and pull downwards towards the base of the phone.

## Step 2




- Remove the battery by levering the battery out, using the cut just below the camera.

## Step 3 — Back Panel



- Use the opening tool to start prying the camera and speaker cover, starting from the battery side.
- Work the opening tool around the border of the camera and speaker cover, until it comes loose.

## Step 4



- Using the T5 Torx screwdriver, remove the six 6mm screws.


## Step 5



- Using the opening tool, pry the back panel from the front panel.
- Work your way around the phone until the panels separate evenly.

*(i)* This step may require a substantial amount of leverage.

## Step 6 — Speaker



- Pull out the speaker with a tweezers or your hands.

This document was generated on 2019-11-07 11:06:37 AM (MST).

To reassemble your device, follow these instructions in reverse order.