



Infant Optics DXR-5 Camera Replacement

The purpose of this guide is to show the steps required to replace the camera of the camera unit for the Infant Optics DXR-5.

Written By: Charles Neal



INTRODUCTION

Ensure that the camera unit is unplugged prior to starting this guide.


Secure screws to avoid losing them.

Screws are small and can pose a possible choking hazard for small children.

TOOLS:



- Phillips #2 Screwdriver (1)

Step 1 — Camera





- Using a Phillips #2 screwdriver, remove the four, 6.0 mm Phillips screws from the back of the camera unit.

Step 2



- Pull up on the two beige tabs to the left and right of the ribbon connected to the camera.
- Pull the ribbon straight out from the camera.

Step 3



- Remove the front face plate of the camera unit by carefully pulling it off.

To reassemble your device, follow these instructions in reverse order.