



Infant Optics DXR-8 Antenna Replacement

Improve range and minimize static.

Written By: Larsha Johnson



INTRODUCTION

Replace the antenna to receive better signal.

TOOLS:



- **Soldering Iron (1)**

Step 1 — Antenna



- At the top right, the insulated wire exposes the antenna.

Step 2



- Locate antenna connection.
- Desolder wire to remove. An antenna of a new length can be soldered to the board for improved signal strength.

 Be careful when using soldering iron.

To reassemble your device, follow these instructions in reverse order.