




# Infant Optics DXR-8 Power Button Replacement

Replacing a faulty power button in the Infant Optics DXR-8 baby monitor.

Written By: Thomas



 **TOOLS:**


- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

## Step 1 — Internal Monitor Components



- Using the plastic opening tool, remove screen protector from front of monitor.

## Step 2



- Remove the six 4mm screws using a size 00 Philips head screwdriver.
- Remove the screen, exposing the circuit board.
- Turn device over to expose rear circuit board.

## Step 3



- Disconnect speaker from monitor for ease of access by unplugging wire.

## Step 4 — Power Button



- The power button is located at the top of the device.

## Step 5



- Remove the button by picking it up out of the hole it is connected to.

## Step 6



- Insert a new button by placing the small end in the hole to connect the button to the device.

To reassemble your device, follow the instructions in reverse order.