



Insignia NS-HTMC01-B Front Case Replacement

This guide instructs how to disassemble an Insignia NS-HTMC01-B heater.

Written By: Emma Walters



 **TOOLS:**

- Phillips #00 Screwdriver (1)

Step 1 — Front Case



- Flip the device over so the back panel faces up.
- Unscrew the four screws counter-clockwise from the back panel using a 4mm Phillips screwdriver.
 - You may want to use a flashlight during this step, as the screws are hard to see.
- ⚠ Make sure to firmly connect your screwdriver with the head of the screw. A loose connection can strip the screw head, making the screws nearly impossible to remove.

Step 2



- Take the screws out and set them aside.
 - Be sure to set them somewhere flat, so they don't roll away.
- Gently pull the front panel and back panel apart to open the device.

To reassemble your device, follow these instructions in reverse order.