Ion Air Pro Power Button Replacement

This guide provides instruction on how to replace the Power Button.

Written By: Christopher Brandl

INTRODUCTION

Is your camera not turning on or turning off? Consider using this guide to replace the power button of your device.

🔧 TOOLS:

- Phillips #00 Screwdriver (1)

This document was generated on 2019-09-19 12:25:21 PM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 2 of 5

Step 1 — Power Button

- Remove the 6 screws that secure the lens cover bezel with a #00 Phillips screwdriver.

Step 2

- Slide off the black aluminum casing.

Step 3

- Unscrew the top screw that is by the power button using a #00 Phillips screwdriver.

⚠️ A spring is being held down by the screw. be sure to hold it down.

Step 4

- Lift off the plastic part holding the power button in place.

This document was generated on 2019-09-19 12:25:21 PM (MST).

Step 5

- Remove the power button from the device.

To reassemble your device, follow these instructions in reverse order.