



# JVC GR-D72U Battery Replacement

Replacement guide for the battery. The battery is what provides power to the JVC GR-D72U.


Written By: Jonah Powers



## INTRODUCTION

Batteries are often the first part of a device that gets replaced. Because of this replacing a battery very simple.

## Step 1 — Battery



- Locate button on bottom of camera.
- Slide button to the right.

## Step 2



- Pull the battery towards the bottom of the camcorder while lifting battery

To reassemble your device, follow these instructions in reverse order. Holding down the battery release switch is not necessary,