



Jam Voice Rubber Base Replacement

Remove or replace the rubber base on the bottom of the Jam voice.

Written By: Hope Bukhamseen



INTRODUCTION

The rubber base may be worn and in need of replacement or to gain access to the underside of the device . Depending on objectives, a new rubber base may be applied or the used base may be reapplied.

TOOLS:

- [iFixit Opening Tools \(1\)](#)

Step 1 — Rubber Base



- Turn the speaker upside down, as shown .
- ☒ When reassembling your device, place the same or a new rubber pad on the bottom of the device using the perpendicular rubber protrusions as a guide for placement.

Step 2



- Use the plastic opening tool to help peel the rubber cover off the base.
- Peel off the rest of the rubber base by hand.

To reassemble your device, follow these instructions in reverse order.