




# Jazz UltraTab C855 Camera Replacement

This guide will show you how to replace a broken camera in your Jazz UltraTab C855 tablet.

Written By: Kyle Haas



## INTRODUCTION

Don't dump your device simply because the camera isn't working! This guide will help you easily replace the faulty camera on your tablet.

---

### TOOLS:


- [Phillips #000 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-

## Step 1 — Back Cover




- Remove the 4 exterior screws using a [Phillips #000 Screwdriver](#).

## Step 2



- Pry the back case off using the blue [Plastic Opening Tools](#). Work one along the seam until you can get your fingers under to pull it apart.

### Step 3 — Camera



- Remove the two screws holding the internal camera in place.


### Step 4



- Carefully remove the tape of the ribbon cables attached to the camera.




## Step 5



- Using a plastic opening tool, lift open the tab that holds the connection between the camera and motherboard in place. The ribbon cable will become detached.

## Step 6



- Finally, detach the camera lenses from the cover by gently pulling them away from the case.

To reassemble your device, follow these instructions in reverse order.