



Kano Computer Kit Complete Speaker Replacement

How to replace the blue speaker in a Kano Computer Kit Complete.

Written By: Julia Sherrill





INTRODUCTION

This is an easy procedure that requires no tools in order to replace the speaker in the Kano Computer Kit.

The speaker will need to be replaced if no sound is coming out or it is distorted or fuzzy.


The only tools needed are your hands.

Step 1 — Speaker




- Take off the clear backing of the computer and set it aside.
- Locate the Speaker.

Step 2




- Unplug the blue power cable from the brain.

Step 3



- Unplug the blue audio jack from the brain.

Step 4



- Pull the speaker up off the back of the screen.

To reassemble your device, follow these instructions in reverse order using the new speaker.