



# Kenwood KDC-BT565U Face Plate Replacement

This guide will walk you through the process of replacing the face plate in a Kenwood KDC-BT565U.

Written By: Darren Evans



This document was generated on 2019-09-18 06:09:49 AM (MST).

## INTRODUCTION

The face plate in a Kenwood KDC-BT565U can be removed to either keep separate from a vehicle, perform a hard reset, or to repair/replace a component. This guide will show you how to replace the face plate.



## PARTS:

- Kenwood KDC-BT565U Replacement Faceplate (1)

## Step 1 — Face Plate



- Press the eject button on the bottom left corner of the face plate.

## Step 2



- Begin by slightly lifting the face plate out from the side located by the release button.
- Slide towards the side of the eject button, *then* completely lift out.

To reassemble or replace, follow the steps in reverse order with the working faceplate.