




Kindle Fire HD 10 Speaker Replacement

This guide will demonstrate how to replace the speakers on the 7th generation Amazon Kindle Fire HD 10.

Written By: Vittorio Custode



 **TOOLS:**

- [iFixit Pro Tech Toolkit \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [Tweezers \(1\)](#)
- [Soldering Iron \(1\)](#)

Step 1 — Speaker




- Pry open the case using the iFixit tool.
- Make sure to go around the whole case before removing the whole case.

Step 2




- After removing the blue casing identify the speakers and wires connected to the motherboard.

Step 3



- Gently pop off the speakers using your fingers where the speakers were located in the previous step.

Step 4



- Remove wires around mother board carefully using iFixit ESD safe tweezer and a soldering iron at the attached point of the speaker cable.

(i) Check out the [How to Solder and Desolder Connections guide](#).

To reassemble your device, follow these instructions in reverse order.