



# KitchenAid KHM512ER Speed Knob Replacement

Replacing the speed knob on the KitchenAid KHM512ER.

Written By: Brad Daniels



## INTRODUCTION

Is your knob stuck or cracked? This guide will demonstrate how to replace the speed control knob on the KitchenAid KHM512ER Mixer.

### TOOLS:

- [iFixit Opening Tools \(1\)](#)

## Step 1 — Speed Knob



- Use a plastic opening tool to pry off the speed knob.

## Step 2



- Pop up the panel with a plastic opening tool.

## Step 3



- Use a plastic opening tool to pry the white plastic switch assembly out.
- Remove the switch with your fingers.

To reassemble your device, follow these instructions in reverse order.