



KitchenAid Professional 600 Gear Housing Cover Replacement

To access the Bevel and Worm gear you need to remove this housing cover.

Written By: Luke



 **TOOLS:**

- Phillips #2 Screwdriver (1)

Step 1 — Top Cover



- Take out the screw which holds on the silver band using a Phillips #2 screwdriver.
- Remove the silver band.

Step 2



- Remove the four Phillips #2 screws located around the mixer where the band was removed.


(i) This picture only shows two of the screw that you need to remove. The other two are on the exact opposite side of the mixer.

Step 3



- Remove the top of the mixer to reveal the inner parts.


Step 4 — Gear Housing Cover



- Remove the 4 Phillips #2 screws connecting the black housing cover to the device.

ⓘ Only one of the screws is seen in the picture. The other three are also located around the black housing cover.

Step 5



- Take off the black housing cover.

To reassemble your device, follow these instructions in reverse order.