



KitchenAid Professional 600 Top Cover Replacement

Written By: Luke



INTRODUCTION

Outline what you are going to teach someone how to do.

TOOLS:

- Phillips #2 Screwdriver (1)

Step 1 — Top Cover



- Take out the screw which holds on the silver band using a Phillips #2 screwdriver.
- Remove the silver band.

Step 2



- Remove the four Phillips #2 screws located around the mixer where the band was removed.

(i) This picture only shows two of the screw that you need to remove. The other two are on the exact opposite side of the mixer.

Step 3



- Remove the top of the mixer to reveal the inner parts.

To reassemble your device, follow these instructions in reverse order.