




# KitchenAid Professional 600 Worm Gear Replacement

The Worm gear works with the Bevel gear to rotate the spindles attached to the mixer.

Written By: Luke



 **TOOLS:**

- Phillips #2 Screwdriver (1)

## Step 1 — Top Cover



- Take out the screw which holds on the silver band using a Phillips #2 screwdriver.
- Remove the silver band.

## Step 2



- Remove the four Phillips #2 screws located around the mixer where the band was removed.
- i* This picture only shows two of the screw that you need to remove. The other two are on the exact opposite side of the mixer.

## Step 3




- Remove the top of the mixer to reveal the inner parts.

## Step 4 — Gear Housing Cover



- Remove the 4 Phillips #2 screws connecting the black housing cover to the device.
- (i)* Only one of the screws is seen in the picture. The other three are also located around the black housing cover.

## Step 5



- Take off the black housing cover.

## Step 6 — Worm Gear



- Remove the Worm Gear.
- (i)* The Worm Gear is the part that is lying horizontal.
- Remember to apply food safe grease onto your new replacement part before assembling the device back together.

To reassemble your device, follow these instructions in reverse order.