




# Kodak Easyshare Z981 Back Cover Replacement

This guide will explain in detail how to replace the back cover of the Kodak Easyshare Z981.

Written By: Olivia Boina



 **TOOLS:**

- Phillips #00 Screwdriver (1)
- iFixit Opening Tools (1)

 **PARTS:**

- Kodak Easyshare Z981 Replacement Back Panel (1)

## Step 1 — Back Cover



- Remove screws using a [00 Phillips-Head](#) screwdriver:
  - Eight (8) **3mm** screws on the lower portion of the camera
    - Four (4) on the bottom of the camera
    - Four (4) inside the battery cover

## Step 2




- Start from a corner and gently remove the bottom cover of the camera.
- *(i)* The cover will easily lift off without much pressure necessary.

## Step 3



- Use a [Phillips #00 Screwdriver](#) to remove the **4 mm** screws from each side of the back cover of the camera.
  - Two (2) screws are located in the left side of the device
  - Two (2) screws are located in the right side of the device

## Step 4



- Use a [Plastic Opening Tool](#) to remove the back of the camera and pull gently on the cover to remove the cover

 Start from one corner and apply light pressure with the tool.

To reassemble your device, follow these instructions in reverse order.