



Kodak Easyshare Z981 Bottom Panel Replacement

Replace the battery cover of a Kodak Easyshare Z981

Written By: Olivia Boina



INTRODUCTION

This guide will explain how you can replace the battery cover on your Kodak Easyshare Z981.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)

Step 1 — Bottom Panel



- Open the battery cover and remove the AA batteries from the camera if any are inserted.

Step 2



- Use a [#0 Phillips-Head](#) screwdriver
- Remove the **3 mm** screws from the camera.
 - Four (4) screws are in the bottom of the device
 - Four (4) screws are inside the battery cover

Step 3



- Start from a corner and gently remove the bottom cover.
- *(i)* The cover will easily lift off, so not much pressure is required.
- *!* Be gentle while removing the cover, to avoid breaking the plastic

Step 4



- Remove the bottom of the battery cover first, and then the top.
- *(i)* The hinge is simple, the screwdriver is no longer necessary.

To reassemble your device, follow these instructions in reverse order.