



# LG CG180 Battery Replacement

Written By: Alex Jacobs



## INTRODUCTION

How to remove the battery from an LG CG180 cell phone.

### TOOLS:

- Fingers (1)

## Step 1 — Battery



- Power down the cell phone by pressing and holding down the red "end call" button.

## Step 2



- Turn the phone screen-down so you are looking at the back cover.

## Step 3



- Slide the back cover down using your finger to remove the cover from the phone.

## Step 4



- Place your finger at the top of the battery in small gap.

## Step 5



- Press downward while pulling outward to remove the battery.

To reassemble your device, follow these instructions in reverse order.