



LG CU515 SIM Card Replacement

This guide shows how to remove your old SIM card from your phone in order to put in a new one.


Written By: Zack Mintzer



INTRODUCTION

The SIM card allows the user to make phone calls.

Step 1 — Battery



- Use your thumb to press down and slide off the back cover of the phone.

Step 2



- Take out the battery by levering it out towards the bottom of the phone.

Step 3 — SIM Card

- Slide the SIM card towards the bottom of the phone by firmly pressing down on the card. This will remove the SIM card.



To reassemble your device, follow these instructions in reverse order.