



LG Muzyq LX570 Battery Replacement

Removing the battery on a LG Muzyq LX570

Written By: Braden Burk



INTRODUCTION

This is a guide to help you remove the battery in your LG Muziq LX570.

Step 1 — Battery



- Slide the battery cover release towards top of phone.
- Place one finger at each side of the battery cover.
- Lift and remove the battery cover.

Step 2



- Place a finger at the top corner of the battery and lift out of the phone.

To reassemble your device, follow these instructions in reverse order.