




LG Optimus T Camera and Camera Mount Replacement

If your LG Optimus T will not take pictures, replacing the camera and camera mount may solve these issues.

Written By: stacey



This document was generated on 2019-10-04 08:42:30 AM (MST).


INTRODUCTION

This guide will show you step by step instructions on how to replace the camera on your LG Optimus T.

TOOLS:

- [Metal Spudger \(1\)](#)
- [Tweezers \(1\)](#)
- [JIS Driver Set \(1\)](#)
- [iFixit Opening Tools \(1\)](#)

Step 1 — Camera



⚠ Working on your device while it is turned on may result in electric shock. Make sure to shut down your device before you begin.


- Use a plastic opening tool to remove the phone's back cover. At the top of the phone there are indentations to insert the spudger and pop the case off

Step 2




- Remove the battery by pulling up on the battery using the indentation to the left of the camera lens

Step 3



- Use a J0 screwdriver to remove the 6 highlighted screws


Step 4



- Remove interior case using indentations on the top and bottom to insert the spudger to pop off the interior case


(i) You might have difficulty popping the interior case off. You may use the metal spudger here with caution if the plastic one fails

Step 5




- Unhook the connector tab

Step 6




- Remove SD card mount by inserting the plastic opening tool on the right side of the device to pop mount off

Step 7



- Remove metal panel by inserting plastic opening tool into the four retaining points and remove panel

Step 8



- disconnect camera connector from motherboard by spudger
- Once disconnected, remove camera using tweezers

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-10-04 08:42:30 AM (MST).

