



LG Optimus V Battery Replacement

How to replace an LG Optimus V battery.

Written By: Joseph Pasquantonio



INTRODUCTION

In this guide, you will learn to replace a cell phone battery

TOOLS:

- [iFixit Opening Tools](#) (1)

Step 1 — Battery



- Turn the LG Optimus V over so that the back cover is facing upward.

Step 2



- Locate the opening right above the camera.
- Use a spudger to detach the back cover.

Step 3



- Gently remove the battery with your spudger.

To reassemble your device, follow these instructions in reverse order.